EN

CERAMIC FAN HEATER



OPERATING INSTRUCTIONS

Read the instructions carefully before installing and operating the appliance or performing maintenance operations. Observe all the safety instructions; failure to observe the instructions may cause accidents and/or damages. Store these instructions for future reference.

GENERAL SAFETY INFORMATION

- Use this ceramic fan heater only as outlined in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock or injury to persons.
- Ensure that the mains power complies with the voltage specified on the fan heater's data plate (230V~/50Hz).
- This product is not a toy. Children should be adequately supervised to ensure that they do not play with the appliance.
- This appliance is not suitable for use by persons (including children) with reduced physical, sensory or mental abilities, or without the necessary experience and knowledge, unless they have been adequately supervised and instructed concerning use of the appliance by a person responsible for their safety.
- Do not cover the appliance or restrict the air inlet and outlet grilles to prevent overheating.
- Ensure that all objects are at least 1 meter from the front and sides of the appliance.
- Disconnect the mains power when the appliance is not used or for cleaning operations.
- Avoid using the fan heater in dusty environments or in the presence of inflammable vapours (e.g. in workshops or garages) or paint vapours.
- Do not use the appliance to dry clothing.
- Use the appliance in a well-ventilated area.
- Avoid placing fingers or foreign objects in the air inlet/outlet grilles, as this may lead to electric shock or fire and may damage the appliance. To avoid the risk of fire, do not block the grilles or tamper with them in any way while the ceramic fan heater operates.
- Do not use the appliance if the cord or plug are damaged. If the power supply cord is damaged, it must be replaced by the manufacturer, dealer or a similarly qualified person so as to avoid any safety risks.
- Do not operate the appliance if it has fallen from a height or has suffered damage in any way. Contact qualified technical personnel to examine the appliance or perform any electrical or mechanical repairs.
- The most common cause of overheating is the build-up of dust in the appliance. Remove dust deposits by unplugging the appliance and cleaning the air outlets and grilles with the aid of a vacuum cleaner.
- Do not use abrasive detergents for cleaning this appliance. Clean the appliance with the aid of a damp (not wet) cloth rinsed in hot soapy water. Always remove the plug from the mains socket before cleaning.
- To disconnect the ceramic fan heater, push the switch to OFF and remove the plug from the socket. Pull on the plug only. Avoid pulling on the cord when disconnecting the ceramic fan heater.
- Do not place any objects on the cord and do not bend it.
- It is not advisable to use extension cords, as these may overheat and cause the risk of fire. Do not use a single extension cord to operate multiple appliances.
- Do not immerse the cord, plug or any other element of the appliance in water or other liquids.
- Do not touch the plug with wet hands.
- Do not place the fan heater above or near another heat source.

WARNING: AVOID COVERING THE FAN HEATER TO PREVENT IT FROM OVERHEATING.
The symbol below signals the above warning:

- The fan heater may cause the risk of fire if, while in operation, is covered by or comes into contact with **inflammable** material including curtains, drapery, blankets, etc. **KEEP THE FAN HEATER AWAY FROM THESE MATERIALS**.
- Do not connect the appliance to the mains power before it has been properly assembled and positioned.

- The appliance heats up slightly when in use. In order to avoid burns, do not let bare skin touch hot surfaces.
- Do not run the cord under carpets. Do not cover the cord with blankets, carpets or similar materials. Place the cord far away from busy areas or where it cannot be accidentally pulled-out.
- Do not operate the fan heater in close proximity to bathtubs, showers, washbasins or pools.
- Do not position the fan heater below a socket outlet.
- Do not operate the appliance outdoors.

WARNING: **do not use the fan heater with a controller or any other external device that activates the appliance automatically, as there may be a risk of fire if the fan heater is covered or incorrectly positioned.**

- Upon initial start-up, the fan heater may emit a slight, harmless smell. This smell is a normal effect of the initial heating up of the internal heating elements, and should not recur later on.
- Non posizionare il termoventilatore sotto una presa.

WARNING:
DO NOT DEPEND ON THE ON/OFF BUTTON SWITCH AS THE SOLE MEANS OF DISCONNECTING POWER. WHEN SERVICING OR MOVING THE HEATER, ALWAYS UNPLUG THE POWER CORD.

ASSEMBLY INSTRUCTIONS

Open the box and remove the 3 parts of the appliance: body, base and remote control unit.

1. Combine the two halves of the base, as shown in the diagram.



2. Undo the element fastening the appliance.



3. Insert the base onto the lower part of the appliance and tighten the fastening element.



4. Stand the appliance up vertically on a level surface before switching on.

DESCRIPTION OF PARTS



FRONT BACK

1. **Soft-touch control panel**
2. **Liquid crystal display**
3. **Air delivery grille**
4. **Carry handle**
5. **Intake grille with filter that can be removed for cleaning**
6. **On/off button**

HOW TO USE THE FAN HEATER

Set up the fan heater in a vertical position on a level and stable surface.
Connect the power cord to a suitable electrical socket (230 V ~).

On/off button (at the base of the rear cover, below the removable air filter)
Bring the on/off button to the “I” position. When the appliance emits a beep this means that the fan heater is ready for use. Bring the button to the “0” position to switch off the fan heater.

LCD DISPLAY



CONTROL PANEL

Buttons
Allow you to adjust the temperature and timer settings of the appliance.

OSCILLATION Button
When the unit is operating, touch the button to make the appliance oscillate automatically, shifting the air flow from left to right. The LED is switched on simultaneously.

Touch the button once again to interrupt the oscillation and switch off the LED.

TIMER / TEMPERATURE Button
When the appliance is operating, the operating time can be set by touching the button: the timer display shows a flashing 0 and the **buttons can be operated to set the desired time, between 1 and 12 hours, with each touch corresponding with 1 hour.** The display shows the set time: wait 5" for the setting to be confirmed. The unit will switch off automatically at the end of the programmed time.

After the timer has been set, touching the **button once again will allow you to set the temperature: the display will show the default temperature of 25°C and,** by operating the buttons, the desired temperature can be set between 15 and 35°C. Once the desired temperature has been set, wait 5" for the setting to be confirmed. After 5" the display will show the ambient temperature once again. If no settings are made, the default temperature is 25°C.When the ambient temperatureis≤-10°C, the LED indicatorwill display"LO", when the ambient temperatureis > 40°C,the LED indicatorwill display"HI". When the ambient temperature isbetween-10°Cand 40°C,the LED indicatorwill displaythe ambient temperature.

ON/OFF (STAND-BY) Button
Touching the button will cause the low power LED to light and the appliance will begin to operate at low heating power (1500W). Touching the button once again will lock all functions and place the unit in stand-by. The power LED will switch off.To switch off the fan heater completely, place the on/off button in the "0" position.

POWER LEVEL SELECTION Button
When the appliance is operating at the low heating power setting, touch the button to switch to the high power setting and activate the LED at "2500W". Press the button once again to switch back to the low power setting and light the LED at "1500W".

REMOTE CONTROL

The remote control has six membrane buttons whose functions are identical to those on the control panel (already illustrated in detail).
Use Lithium/Manganese button cells, model no. CR2032 -3 V, compliant with Battery Directive no. 2006/66/CE (supplied with the remote control).

HOW TO INSERT / REMOVE THE REMOTE CONTROL BATTERIES
(refer to the diagram below)
Open the battery cover at the rear of the remote control (press and pull the cover).
Place the battery into the cover, observing the correct polarity.
Insert the cover onto the remote control.





Information for correct disposal of the battery in accordance with the European Directive 2006/66/EC
Please replace battery when its electricity charge is used up: please do not eliminate this battery together with normal household waste. It must be taken to special local community waste collection centres or to a dealer providing this service. Disposing of a battery separately avoids possible negative effects on the environment and human health deriving from an inappropriate disposal and enables its components to be recovered and recycled to obtain significant savings in energy and resources. In order to underline the duty to dispose of this equipment separately, the battery is marked with a crossed-out dustbin.

MAINTENANCE

ALWAYS UNPLUG THE APPLIANCE BEFORE CLEANING OR MAINTENANCE.
IMPORTANT: DO NOT SUBMERGE THE CERAMIC FAN HEATER IN WATER

Cleaning the outside surface of the appliance
Use a soft cloth to remove any dust from the fan heater.
If the fan heater is excessively dirty, use a soft cloth moistened with water and a mild detergent at a temperature lower than 50°C. Let the fan heater dry completely before use.
Do not use corrosive detergents or solvents such as petrol. Do not wash the appliance with water. Do not use oils, chemical substances or other items to clean that may damage the surface.
Use a vacuum cleaner to remove dust from the air inlet/outlet grilles.

Cleaning the filter
Clean the filter frequently, based on the environmental conditions under which the appliance is used: a dirty filter may reduce the air flow rate and prevent the fan heater from working properly. Remove the filter by pulling as shown in the diagram below. Clean the filter using a vacuum cleaner and wash in water using a neutral detergent at a temperature below 30°C.
Leave the filter to dry after washing and refit it on the fan heater.



STORAGE
If the appliance is not used for prolonged periods, it must be stored together with this manual in its original packaging, in a cool and dry place.

Information for correct disposal of the product in accordance with the European Directive 2002/96/EC
At the end of its working life this equipment must not be disposed of as an household waste. It must be taken to special local community waste collection centres or to a dealer providing this service. Disposing of electrical and electronic equipment separately avoids possible negative effects on the environment and human health deriving from an inappropriate disposal and enables its components to be recovered and recycled to obtain significant savings in energy and resources. In order to underline the duty to dispose of this equipment separately, the product is marked with a crossed-out dustbin.

argo
improve your life

www.argoclima.com

MADE IN CHINA